

STUDIO FLASH MONOLIGHT

D-Lite RX ONE D-Lite RX 4



D-Lite RX ONE (20485.1.XX)
- Flashtube (24009)



D-Lite RX 4 (20487.1.XX)
- Flashtube (24009)



D-Lite RX ONE Newborn Kit
(20490.1.XX)



D-Lite RX ONE/ONE Softbox To Go (20847.2.XX)



D-Lite RX 4 First Studio Kit
(20491.1.XX)



D-Lite RX 4/4 Softbox To Go (20839.2.XX)

ELC 500 ELC PRO HD 500 ELC PRO HD 1000



ELC 500 (20619.1.XX)
- Flashtube (24092)



ELC 500 Pro HD (20613.1.XX)
- Flashtube (24084)



ELC 1000 Pro HD (20616.1.XX)
- Flashtube (24084)



ELC 500 Studio Portrait Kit
(20920.1.XX)



ELC 500 / 500 - Dual Monolight Kit
(20737.2.XX)



ELC Pro HD 500 Dual Monolight Kit
(20662.2.XX)



ELC Pro HD 1000 Dual Monolight Kit
(20663.2.XX)

BATTERY FLASH MONOLIGHT

ELINCHROM FIVE



Elinchrom FIVE - Battery Monolight Kit
(20960.1)
- Flashtube (24092)



FIVE Outdoor Portrait Kit
(20970.1)



Elinchrom FIVE - Battery Monolight Dual Kit
(20961.2)
- Flashtube (24092)



Elinchrom FIVE Battery
(20962)



Elinchrom 65W USB-C Wall Charger
(11052)



Elinchrom THREE-FIVE Case
(33255)



Elinchrom Storage Bag
(33236)

OFF CAMERA FLASH

ELINCHROM ONE ELINCHROM THREE



Elinchrom ONE - Off-Camera Flash Kit
(20932.1)
- Flashtube (24091)



Elinchrom ONE - Dual Off-Camera Flash Kit
(20931.2)
- Flashtube (24091)



Elinchrom THREE - Off-Camera Flash Kit
(20941.1)
- Flashtube (24091)



Elinchrom THREE Dual Off-Camera Flash Kit
(20942.2)
- Flashtube (24091)



OCF Diffusion Dome
(25110)



OCF Gel Dome Kit
(25112)



OCF Adapter
(26346)



OCF Wide Reflector 16 cm (6.3")
(26090)



OCF Barndoors
(26002)



EL-ProfotoAdapter
(26345)



Elinchrom 65W USB-C Wall Charger
(11052)



Elinchrom ONE-THREE Backpack
(33252)



Elinchrom ONE Case
(33250)
Elinchrom THREE-FIVE Case
(33255)

ELB 500 TTL



ELB 500 TTL - Off-Camera Flash Kit
(10309.1)



ELB 500 TTL - Dual Off-Camera Flash Kit
(10310.1)



ELB 500 TTL One Light Portrait Kit
(10300.1)



ELB 500 Head (20190)
- Flashtube (24009)



Q-Reflector Adapter MKII
(26342)



Q-Wide Reflector 13.5 cm
(26145)



Q-Reflector Grid 18 cm
(26056)



Q-Protective Cap
(25101)



ELB 500 Snappy
(19254)



Elinchrom Storage Bag
(33236)



ELB 500 Battery
(19297)



ELB 500 Charger
(19277)



Extension Cable 5 m
(11003)

ACCESSORY CHART



SOFTBOXES

ROTALUX



Rotalux Square 70 cm (27.5") (26642) External Diffuser (26721) Rotagrid Square (26774)
Rotalux Square 100 cm (39") (26643) External Diffuser (26722) Rotagrid Square (26782)
Rotalux Recta 60 x 80 cm (23.6x31.5") (26640) External Diffuser (26713) Rotagrid Recta (26772)
Rotalux Recta 90 x 110 cm (35.5x43") (26641) External Diffuser (26714) Rotagrid Recta (26773)
Rotalux Strip 35 x 100 cm (14x39") (26644) External Diffuser (26723) Rotagrid Strip (26775)
Rotalux Strip 50 x 130 cm (20x51") (26645) External Diffuser (26724) Rotagrid Strip (26776)
Rotalux Octa 100 cm (39") (26646) External Diffuser (26716) Rotagrid Octa (26777)
Rotalux Octa 135 cm (53") (26647) External Diffuser (26717) Rotagrid Octa (26778)
Rotalux Octa 175 cm (69") (26649) External Diffuser (26715) Rotagrid Octa (26780)



Rotalux Deep Octa 70 cm (27.5") (26650) External Diffuser (26702) Rotagrid Octa (26781)
Rotalux Deep Octa 100 cm (39") (26648) External Diffuser (26716) Rotagrid Octa (26777)

SPEEDRINGS FOR ROTALUX



Elinchrom (26570)
Bowens/S Mount (26571)
Broncolor (26573)
Profoto (26574)
Hensel EH (26544)
Comet (26535)
Photona (26536)
Alienbee/Balcar (26545)

ROTALUX INDIRECT



Rotalux Deep Octa Indirect 150 cm (59") (26188) External Diffuser (26703) Rotagrid Indirect (26779)



Rotalux indirect Speedring (26329)

ROTALUX GO



Rotalux Go Strip Softbox 35x75cm (14x30") (26632)
Rotalux Go Recta Softbox 55x75 cm (22x30") (26633)
Rotalux Go Octa Softbox 60 cm (24") (26634)

ROTALUX GO ADAPTERS



Elinchrom (26561)
Q-Mount (26562)
Profoto (26563)
Bowens/S Mount (26564)
Broncolor (26565)
Alienbee/Balcar (26566)

LITEMOTIV



Litemotiv Direct Para 190 cm (75") (28005)



Litemotiv Direct Para 120 cm (47.3") (28004)

LITEMOTIV BRACKET



Elinchrom (26537)
Bowens (26538)
Profoto (26539)
Broncolor (26540)

LITEMOTIV INDIRECT



Indirect Litemotiv Square 145 cm (57") (28001)



Indirect Litemotiv Octa 190 cm (75") (28000)

REFLECTORS, GRIDS & ADAPTERS



Wide Reflector 16 cm (6.3") (26170)
Standard Reflector 21 cm (8.3") (26171)
High Performance Reflector 26 cm (10.2") (26071)
Grids 21 cm (8.3") 12° (26054) 20° (26053) 30° (26052)
Background Reflector 32 x 21 cm (12.5x8.3") (26066)



Softlite White Beauty Dish 44 cm (17.3") White (26069) Silver (26067)
Softlite Beauty Dish Reflector 70 cm (27.6") White (26070) Silver (26068)
Softlite Beauty Dish Grid 70 cm (26022) 44 cm (26020)
Softlite Beauty Dish Diffusion Cap Softlite 70 cm (26235) Softlite 44 cm (26232)



10 Colour Filter 21 cm (8.3") (26243)
20 Advanced Colour Filters 21 cm (8.3") (26256)
Snoot & Grid 15" (26061)
EL-Profoto Adapter (26345)
EL-Bowens Adapter (26335)

KIT



Deflector Kit (26310)
Barndoor 21cm (8.3") Kit (26041)
Standard Reflector & Grid 21cm (8.3") Kit (26050)
Grid Kit 21 cm (8.3") (26011)

REMOTE CONTROLS

TRANSMITTERS



Elinchrom Transmitter Pro

Canon (19366)
Sony (19371)
Nikon (19367)
FujiFilm (19337)
Pentax (19336)



Elinchrom Transmitter Plus (19368)

RECEIVER



Elinchrom Receiver Plus (19369)

COMPUTER & SMARTPHONE CONTROL



Elinchrom Bridge (19338)



Elinchrom Transmitter and Receiver Plus Kit (19370)

UMBRELLAS

SHALLOW



Shallow Silver Umbrella 105 cm (41") (26348) 85 cm (33") (26350)
Shallow Translucent Umbrella 105 cm (41") (26349) 85 cm (33") (26351)
Umbrella Shallow White/Translucent 105 cm (41") (26359) 85 cm (33") (26358)

DEEP



Deep Silver Umbrella 105 cm (41") (26352) 125 cm (49") (26353)
Deep White Umbrella 105 cm (41") (26356) 125 cm (49") (26357)
Deep Translucent Umbrella 105 cm (41") (26354) 125 cm (49") (26355)
Deep Black Diffuser 105 cm (41") (26763) 125 cm (49") (26764)
Deep Translucent Diffuser 105 cm (41") (26761) 125 cm (49") (26762)

KIT



ECO Umbrella Kit (26062)
Umbrella Portrait Kit (26363)
Umbrella To Go Kit (26362)

BAGS & CAPS



Tube case for D-Lite RX ONE (33194) **D-Lite 4** (33198)
Elinchrom Storage Bag (33236)
Elinchrom ONE-THREE Backpack (33252)
Elinchrom ONE Case (33250)
Elinchrom THREE-FIVE Case (33255)
Elinchrom Hardshell Case for Remotes (33238)
Grid Bag for 18 cm and 21 cm (33217)



Protective Cap MK-II (27124)



Protective Cap MK-III (27125)



Q-Protective Cap (25101)

TRIPODS



Tripod Air Click 105-244 cm (31038)
Tripod 88-235 cm (30101)
Boom Arm 63-156 cm (31049)
Tripod Set 2 (30162)